

Please Read before Proceeding

- If the security lock is on, deactivate it. After work is complete, activate the security lock again.
- Start work after ensuring that the power has been turned off.
- After cleaning is complete, check to ensure that all dismantled parts are restored to their original positions. Failure to restore the parts may result in malfunction of the printer.
- For details on separately sold items, please consult our authorized dealers.

Maintenance of Card Load Roller

Card jams may occur if the card load roller is dirty.

1. Remove the card hopper
2. Apply alcohol (sold separately) to a wiper (sold separately), and use it to wipe the surface of the card load roller
 - Wipe while turning the card load roller in the anti-clockwise direction.
3. Install the card hopper

